

Troubleshooting Hydro Harvest Submersible Pump

Pump does not run

Power is off -Turn power on

Power failure-Check power supply or contact local power company

Power cord is not connected- Connect power cord

Impeller is stuck

Remove debris/clean impeller

Pump stops after starting or Pump is overheating

Submerge pump/Raise water level/Allow pump to cool/Clean impeller

Power/Current overload

Check length/size of power cable.

Diminished flow rate or no water flow

Impeller needs cleaned

Filter needs cleaned- remove and rinse thoroughly

Low water level

Stop operation/Raise water level

Air-lock in the impeller chamber

Place pump in water. Turn the pump ON/OFF intermittently 2 or 3 times.

If all else fails please call John 941-915-7208 or

email john@hydroharvestfarms.com